

# Peterbilt Seat Operating Instructions

**Suggested Control Setting Order:**

- 1) set seat fore/aft slide
- 2) set seat height
- 3) set pan length
- 4) set pan angle
- 5) set back angle
- 6) set lumbar / bolster
- 7) adjust suspension firmness
- 8) adjust steering wheel
- 9) adjust mirrors

**Armrest Angle:**  
Rotate knob to change angle

**#5 Back Angle:**  
Adjust the angle to support the upper back.

**6a Bolster:** (703 feature only) Adjusts seat back width  
**6b Lumbar:** Fill the lower bag first (forward control) and then the upper bag if needed.

**#2 Seat Height:** Height setting changes up or down per click. The seat will return to set height if weight is in seat. Adjust so your thigh is level with the floor or the pan tilt

**#7 Suspension Stiffness:**  
Forward=Firmer  
Backward=Softer

**Air Suspension-Quick Down:** Push to release the air from the suspension. Push again to return the seat to the pre-set height.

**#1 Seat Fore/Aft Slide:** Adjust so you can comfortably reach all the fully depressed pedals

**#3 Pan Length:** Adjust to support as much of your leg as possible, without interfering with the back of your knee.

**#4 Pan Angle:** Adjust angle to distribute the sitting pressure across the whole pan surface without focused pressure on the back of the legs or tailbone, including during pedal position.

**Fore/Aft Isolator:** Rotating the handle down allows motion, up locks the isolator

